



Retrofitting Hubs



Keyed Shafts

Fill the keyway with a half key and then treat as a straight shaft.

Tapered Shafts

Make a split bushing with an internal taper and a straight outside

Splined Shafts

Make a split bushing with an internal matching female spline and a straight outside